Copy this drawing to a piece of wood, plywood or plastic, and carve out along the curved outlines.

Put the edge of the tools on the concave curving surface to be measured. Turn the tool until you find the radius that best fits the curve of the measured object.

